

# BLB CABINET

**Framed**  
Cabinet Box Construction

 **Cabinets.com**<sup>®</sup>

## Notes on Installation

A Universal Filler (ordered separately) is required for proper installation.

We recommend a minimum 3" wide filler. This will allow the drawers on perpendicular cabinetry to safely clear the blind's drawer/door hardware.

- **A** = Overall cabinet width
- **B** = Actual face frame door/drawer opening width
- **X** = **Recommended** overall width of wall space required for installation

Cabinets installed at minimum pull distances may not allow for proper clearance of drawer hardware on perpendicular cabinetry. If used perpendicular to an appliance, pull distances should be determined by actual placement prior to installation to ensure proper drawer and door clearances.

## Maximum and Minimum Pull Dimensions

Cabinet	<b>A</b>	<b>B</b>	<b>X</b> min. - max.
BLB36/39*	27"	8-3/4"	38"-40"
BLB39/42*	33"	11-3/4"	41"-43"
BLB42/45*	39"	14-3/4"	44"-46"
BLB45/48*	45"	17-3/4"	47"-49"

\*First number indicates recommended overall space for standard-overlay door styles.  
Second number indicates recommended overall space for full-overlay door styles.  
All Cabinets.com fully-assembled cabinet door styles are full-overlay.

